Erratum

p6 du manuel d'utilisation vous devriez lire/p6 of the user manual you should read:

Serial Number	General Description	Function Description	Different Color Description	
(1)	RF antenna connector	connect with antenna	\	\
(2)	red&black power	Power supply	red	Power+ +13.8V
(3)			black	Power- GND
(4)	audio connector Black cinch	Hailer	white	HAILER+
			black	HAILER-
(5)	audio connector Black 3.5mm jack	External Speaker	Red	AUDIO+
			white	AUDIO-
			Bare	GND
(6)	Mini-DIN black	NMEA0183 & NMEA2000	Orange	0183_IN+
			Yellow	0183_IN-
			Black	0183_OUT+
			Red	0183_OUT-
			Brown	CANL
			Green	CANH
			Bare	GND
(7)	Mini-DIN yellow	TEST & USB	Brown	GND
			Yellow	NC
			Orange	Speaker
			Black	Mic
			Red	USB_RX
			Green	USB_TX
			Bare	GND
(8)	GND connection hole	\	\	\

Alimentation

Utilisez exclusivement le câble d'alimentation avec fusible fourni.

Only use the power cable with fuse supplied.